

ENERGEN™ Light Mini

User Manual


Caution:

- Light Mini and the cable are not water resistant. Always keep Light Mini dry.
- Do not leave Light Mini exposed to direct sunlight or extreme heat for extended period of time.
- Recycle or dispose Light Mini properly. Disposal in fire may cause battery leaking or explosion.
- When not in use, unplug Light Mini from the charging cable and all devices.

Note:

- Charge your Light Mini for the FIRST time for a full of 8 hours before regular use. After the initial charge, normal charging will take approximately 3~4 hours.
- Light Mini may become warm during charging or in use.

Product Illustration



Charging Energen Light Mini:



- 1 Plug in the micro USB adapter tip to the round female connector of the cable.
- 2 Insert the USB end of the cable to the power source which comes with a USB port. For example, the USB port from your notebook, desktop, car charger or power outlet.
- 3 Insert the micro USB end of the cable into the micro USB port of tEnergen Light Mini. The blue LED indicator starts blinking.
- 4 When fully charged, the LED indicator will be solid blue.

Charging your device using Energen Light Mini:



- 1 Insert the USB end of the cable into the USB port on top of the Light Mini.
- 2 Connect the tip to your device and press the "Function Button" to start charging.
- 3 Remove your device from Light Mini when fully charged.

LED Flash Light Function:

1. Press the "Function Button" for 3 seconds, the LED flash light turns on.
2. Press the "Function Button" for 3 seconds, the LED flash light turns off.